

MPLAB XC8 Compiler PRO Dongle License

Part Number: SW006021-DGL

BUY
IT NOW



Share

The MPLAB® XC8 C Compiler is a full-featured, highly-optimized ANSI C compiler for all 8-bit PIC Microcontroller families. This compiler integrates into Microchip's MPLAB X IDE, is compatible with all Microchip debuggers and emulators, and runs on Windows®, Linux® and macOS®.

The MPLAB XC8 PRO Compiler Dongle License unlocks the full potential and performance of all possible optimizations with the advantage of being interchangeable among workstations and highly portable – not tied to a PC or workstation. Some of its features include:



- License file is installed on a USB device
- Intended for multiple users and mobile use – plug into the workstation's USB and go
- Includes unlimited updates to new compiler versions without the need for HPA (perpetual license)
- One dongle license is needed for each compiler type – MPLAB XC8, MPLAB XC16 and MPLAB XC32/XC32++
- Replaceable for a fee – **only dongle licenses that have been registered in a mySoftware account are eligible**
 - Register your dongle here: www.microchip.com/mysoftware
 - Replacements can be obtained through [Technical Support](#) and can only be replaced once

For more information and documentation, go to: <http://www.microchip.com/mplabxc>.

Note: This compiler license can only be used with the following versions of MPLAB X IDE and MPLAB XC C Compilers:

- MPLAB X IDE version 3.55 or later
- MPLAB XC8 C Compiler version 1.41 or later
- MPLAB XC16 version 1.31 or later
- MPLAB XC32 version 1.43 or later

If there is a compiler license file previously installed on your workstation, remove it before using a dongle license.

Features

Package Contents





Host System Requirements

- License file is installed on a USB device
- Intended for multiple users and mobile use – plug into the workstation's USB and go
- Includes unlimited updates to new compiler versions without the need for HPA (perpetual license)
- One dongle license is needed for each compiler type – MPLAB XC8, MPLAB XC16 and MPLAB XC32/XC32++

- Replaceable for a fee with registration in mySoftware account

Documentation & Software

[Back To Top](#)

Documents	Last Updated	Size	
MPLAB XC8 User's Guide	12/14/2016 11:12:17 AM	5MB	
MPLAB XC8 User's Guide for Embedded Engineers	9/15/2016 2:31:44 PM	340KB	
MPLAB XC8 User's Guide for Embedded Engineers Code Example	8/21/2015 7:18:02 AM	1MB	
MPLAB XC8 Getting Started Guide	8/12/2013 10:26:56 AM	2MB	



[Products](#) | [Applications](#) | [Design Support](#) | [Training](#) | [Sample and Buy](#) | [About Us](#) | [Contact Us](#) | [Legal](#) | [Investors](#) | [Careers](#) | [Support](#)

©Copyright 1998-2017 Microchip Technology Inc. All rights reserved.

